

TRUCKBOSS Decks: SidexSide/UTV Fit Guide



To find measurement:

1) Determine the frontmost point:

When loading, this is the point on the SidexSide/UTV that would touch the headache rack first. In the left example, the front wheels are the frontmost point. In the right example, the front bumper is the frontmost point.

2) Determine the ground-contact rearmost wheel point:

This point is located at the back of the rear wheels where they touch the ground - see the diagram above. In order to safely load a SidexSide./UTV onto a deck, the rear wheel must be fully in contact with the deck surface.

3) Measure between the two points:

Measuring along the ground, run a tape measurer from the frontmost point to the rearmost wheel point.

What this measurement means:

This is the minimum length needed to fit the SidexSide on a deck. Keep in mind that a TRUCKBOSS-SHORT deck has a deck surface length of 70", a TRUCKBOSS-STD has a deck surface length of 82", and a TRUCKBOSS-LONG has a deck surface length of 101".

*For instance; if your point to point measurement was 82" or less your SidexSide/UTV will fit on a TRUCKBOSS-STD deck.